



Aquapac Fit Guide

Sizes indicate the largest item that will fit in each case


084 - Flip-Phone Case




104 - Mini Phone/GPS Case




114 - Small Phone/GPS Case




124 - Medium Phone/GPS Case




210 - Small Armband Case




212 - Large Armband Case




224 - Small VHF Classic




244 - Large VHF Classic




225 - Small VHF PRO




245 - Large VHF PRO



344 - Small PDA Case



364 - Large PDA Case




404 - Mini Camera Case




414 - Small Camera Case




420 - Small Camera Case w/Hard Lens




445 - Large Camera Case




455 - SLR Camera Case




465 - Barrel Camcorder Case




515 - MP3 Case




604 - Keymaster



654 - Small Whanganui




664 - Large Whanganui




674 - Jumbo Whanganui




748 - Seti Case



804 - Kaituna Map Case



824 - Belt Case



154 - Radio Microphone Case

